


### PMT's for THE OPERATION in HIGH MAGNETIC FIELDS over 1 TESLA



In recent years, the demand for photodetectors, that can be operated in strong magnetic fields has increased, especially in the field of high energy physics. Conventional PMT's electrons trajectories are affected by magnetic fields. The gain of these PMT's is decreased under such conditions. Therefore, it is necessary for these PMT's to either use a light guide to send signal light to a region outside the magnetic field or to use a magnetic shield. The light guide and its coupling to a PMT, cause loss of light and deterioration of the timing characteristics of the signal light. The use of magnetic shield adds cost and energy loss for the next particle detector.

PMT's using fine mesh dynodes (Fine Mesh PMT's) make it possible to operate PMT's even in strong magnetic fields over 1.0 tesla. Depending on your needs, you can select from the Fine Mesh PMT series.

In addition, socket assemblies and hybrid assemblies can be supplied to avoid troublesome design and manufacturing of voltage dividers.

#### APPLICATION


- TOF COUNTER
- CALORIMETER
- OTHER DETECTORS IN HIGH ENERGY PHYSICS  
AND NUCLEAR PHYSICS EXPERIMENTS



FINE MESH PMT SERIES for HIGH MAGNETIC FIELD ENVIRONMENTS




Fig.1: Typical Spectral Response




TPMHB0329EA

Fig.2: Typical Current Amplification




TPMHB0258EB

Fig.5: R5505 Typical Current Amplification in Magnetic Fields




TPMHB0156EB

Fig.6: R5946 Typical Current Amplification in Magnetic Fields




TPMHB0248EA

Fig.3: Typical Time Response




TPMHB0259EB

Fig.4: Typical Pulse Linearity




TPMHB0260EB

Fig.7: R5924 & R6504 Typical Current Amplification in Magnetic Fields



TPMHB0247EB

Fig.8: R5542 Typical Current Amplification in Magnetic Fields



TPMHB0249EA

FINE MESH PMT SERIES for HIGH MAGNETIC FIELD ENVIRONMENTS



ASSEMBLIES for FINE MESH PMT SERIES

Type Number	PMT		Outline Number	Ground Potential	H.V. Input Terminal	Signal Output Terminal	Material of Case <sup>a</sup>	Total Resistance ( MΩ)	Maximum Rating			Notes
	Tube Diameter	Type Number							Overall Voltage (V)	Divider Current (μA)	Average Anode Current (μA)	

SOCKET ASSEMBLIES

E6133-03	25mm (1")	R5505	①	ANODE	COAXIAL CABLE (with SHV)	RG-174/U (with BNC)	POM	5.61	2300	410	10(at 2000V)	
E6113-02	38mm (1.5")	R5946	②	ANODE	COAXIAL CABLE (with SHV)	RG-174/U (with BNC)	POM	5.94	2300	390	10(at 2000V)	
E6132-02	51mm (2")	R5924-01	③	ANODE	COAXIAL CABLE (with SHV)	RG-174/U (with BNC)	POM	6.93	2300	330	17(at 2000V)	


HYBRID ASSEMBLIES (PMT INCLUDED)

H6152-01	25mm (1")	R5505	④	ANODE	COAXIAL CABLE	RG-174/U	POM	5.61	2300	410	10(at 2000V)	
H6153-01	38mm (1.5")	R5946	⑤	ANODE	COAXIAL CABLE	RG-174/U	POM	5.94	2300	390	10(at 2000V)	
H6614-01	51mm (2")	R5924	⑥	ANODE	COAXIAL CABLE	RG-174/U	POM	6.93	2300	330	17(at 2000V)	
H6155-01	76mm (3")	R5542	⑦	ANODE	COAXIAL CABLE	RG-174/U	POM	6.93	2300	330	17(at 2000V)	

<sup>a</sup> POM : Poly Oxy Methylene

Dimensional Outlines and Circuit Diagrams for PMT Socket Assemblies

① E6133-03







# FINE MESH PMT SERIES for HIGH MAGNETIC FIELD ENVIRONMENTS

## Socket Dimensional Outlines



Unit: mm

E678-17A





TACCA0046EB

E678-19D



TACCA0067EB

E678-21A



TACCA0011EB

## Warranty

All Hamamatsu photomultiplier tubes are warranted to the original purchaser for a period of 12 months following the date of shipment. The warranty is limited to repair or replacement of any defective material due to defects in workmanship or materials used in manufacture.

A: Any claim for damage of shipment must be made directly to the delivering carrier within five days.

B: Customers must inspect and test all photomultiplier tubes within 30 days after shipment. Failure to accomplish said incoming inspection shall limit all claims to 75% of invoice value.

C: No credit will be issued for broken detectors unless in the opinion of Hamamatsu the damage is due to a bulb crack traceable to a manufacturing defect.

D: No credit will be issued for any photomultiplier tubes which in the judgement of Hamamatsu has been damaged, abused, modified or whose serial number or type number have been obliterated or defaced.

E: No photomultiplier tubes will be accepted for return unless permission has been obtained from Hamamatsu in writing, the shipment has been returned prepaid and insured, the photomultiplier tubes are packed in their original box and accompanied by the original datasheet furnished to the customer with the tube, and a full written explanation of the reason for rejection of each photomultiplier tubes.

F: When photomultiplier tubes are used at the condition which exceeds the specified maximum ratings or which could hardly be grasped, Hamamatsu will not be responsible to the guarantee of photomultiplier tubes.

HAMAMATSU is always in pursuit of improvements and new developments in the field of photodetectors. We can provide various kinds of detectors, emitters and assemblies for use in high energy physics as well as other fields of physics. Please feel free to contact us at any time.

# HAMAMATSU

HAMAMATSU PHOTONICS K.K., Electron Tube Center  
314-5, Shimokanzo, Toyooka-village, Iwata-gun, Shizuoka-ken, 438-01 Japan, Telephone:(81)0539/62-5248, Fax:(81)0539/62-2205, Telex:4225-186HAMA HQ

U.S.A.: Hamamatsu Corporation: 360 Foothill Road, P.O.Box 6910, Bridgewater, N.J. 08807-0910, U.S.A., Telephone:(1)908-231-0960, Fax:(1)908-231-1218

Germany: Hamamatsu Photonics Deutschland GmbH: Arzbergerstr. 10, D-82211 Herrsching am Ammersee, F.G. Germany, Telephone:(49)08152-3750, Fax:(49)08152-2658

France: Hamamatsu Photonics France: S.A.R.L.: 8, Rue du Saule Trappu, Parc du Moulin de Massy, 91882 Massy Cedex, France, Telephone: 33-(1) 69 53 71 00, Fax: 33-(1) 69 53 71 10

United Kingdom: Hamamatsu Photonics UK Limited: Lough Point, 2 Gladbeck Way, Windmill Hill, Enfield, Middlesex EN2 7JA, United Kingdom, Telephone:(44)0181-367-3560, Fax:(44)0181-367-6384

North Europe: Hamamatsu Photonics Norden AB: Färögatan 7, S-164 40 Kista, Sweden, Telephone:(46)08-703-2950, Fax:(46)08-750-5895

Italy: Hamamatsu Photonics Italia S.R.L.: Via Monte Grappa 30, 20020 Arese, Milano, Italy, Telephone:(39)02 935 81 733, Fax:(39)02 935 81 741

Spain: Hamamatsu Photonics Espana S.L.: Centro de Empresas de Nuevas Tecnologias Parque Tecnologico del Valles 08290 Cerdanyola, (Barcelona), Spain Telephone:(34)3 582 44 30, Fax:(34)3 582 44 31

TPMH1110E01  
OCT. 1995 T  
Printed in Japan (2,000)